

To activate banner printing, choose [Allow].

BANNER PRINTING KONICA MINOLTA DEVICES

Bookmark

Display Keypad

Utility



Banner Printing

- When designing your banner you will need to ensure that your page size is set to the banner size you wish to print. Max: 297 x 1200mm
 - When printing you will then need to select - printer properties
 - On the Basic Tab select Original Size.
 - Scroll to bottom of drop down menu and select Custom.
 - Enter the size of the banner.
 - Ok
 - A pop up will come up advising changing paper settings to bypass try.
 - Click OK
 - Go to the MFD
 - select Utility (Right hand side of user panel)
 - Select Banner Printing
 - Click on Allow
- THE MFD IS LOCKED DOWN WHEN THIS IS DONE AND NO-ONE CAN PRINT , SCAN OR COPY TO IT TILL THE BANNER PRINTING MODE IS DISABLED AGAIN!!**
- Place banner paper in the bypass tray, go back to the PC as select print.

Allow

Restrict

12/16/2011 15:43

OK